



SINGER® Presser Feet Expand the Capabilities Of Your Machine

SINGER® makes it simple and easy to find which presser feet are compatible with your machine. Located on the back panel of each presser foot, machine codes are listed. Match the machine series code with your machine number.



CA Series

Brilliance

5400	6180	C5200
5500	6199	
6160	6699	



CC Series

9900

Quantum 9910	Quantum 9960
Quantum 9920	9985 Quantum Stylist Touch
Quantum 9940	9980 Quantum Stylist
	9970



CB Series

Curvy

5625
8763
8767
8770
8780
Athena 2009

One/160

Singer One
Singer One Plus
70
8768

Cosmo/Confidence

S800	7412	7444	7466
5625	7422	7446	7469
7256	7424	7448	7469Q
7256 HC	7426	7462	7470
7258	7430	7463	7563
7285Q	7436	7464	
Patchwork	7442	7465	
7410			



CD Series

IEF RANGE

C240



CE Series

Computerized

2010	H74
7140	Stylist 9100
ET-1	9340
Futura 4060	9100 Professional

Heavy Duty

HD6600
HD6700
HD6800



Futura

FQ-4	XL400
SEQS-6000	XL420
SEQS-6700	XL550
5 Futura Quintet	XL580
8500Q Modern Quilter	

EA Series



Superb / Legacy

EM200	C440Q
SE300	C440
SE340	

EB Series



14CG/14ET/14HD/14SH

14CG-754	14SH-654	14SH-764
14ET-754	14SH-744	14HD854
14SH-644	14SH-754	

SA Series



MA Series

Mechanical

1507	M1500
1507WC	M1600
1525/1725	M2100
1748	M2400
8280	M3200
8280L	M3300
8280	M3400
SMART II	M3500
1105	HD6380
1116	HD6330
1120	(Denim)
1130	CP6350M
7020	(Cosplay)

Simple

1732
2932
3116
3221
3232
3210 Simple
3223 Simple
3229 Simple

Tradition

2250
2259
2263
2273
2277
2282

Promise

1408
1409
1412
Promise
1512
Promise II



MB Series

Heavy Duty

4411
4423
4432 HD
5511
5523

Talent

5532
44S
3321
3323S
3323



MC Series

Fashion/Inspiration

4205	4218
4206	4220
4210	4228
4212	